

Steering Blade Grip Kit

GK

Non-abrasive grip for the back of steering paddles

WHAT'S INCLUDED

- 3x ~15" strips of non-abrasive grip tape
- 1x alcohol prep pad

WHAT YOU'LL NEED

- Scissors or a utility knife
- Pencil
- Plastic scraper (for removing old grip)

INSTALLATION

Inspect your blade before applying. Do not cover cracks, soft spots, or delamination with grip tape. Repair any damage first.

1. Remove the old grip and adhesive. Clean with the alcohol wipe and let dry.
2. Dry fit: lay the center strip down the middle of the blade, backing on. Mark its length.
3. Lay each edge strip along its edge, overlapping the center strip. Mark where they cross.
4. Take the strips off the paddle and cut on your marks with a straightedge. Shape the ends now if you want.
5. Apply the center strip, peeling the backing as you go and smoothing out bubbles.
6. Apply the edge strips, butting them against the center strip.
7. Trim the excess along the blade edge with a utility knife, taking care not to cut into the blade. Round the corners and press everything down firmly.

⚠ IMPORTANT

1. Do all cutting and shaping before you peel, except the final trim along the blade edge. Once the adhesive touches the blade, a strip can't be repositioned without weakening the bond.
2. Never cut tape on the blade except along its outer edge. A knife pressed down on the blade face will score the finish.
3. Wait 24 hours before paddling. The adhesive reaches full strength in about 72 hours.

DISCLAIMER

By purchasing and using this product, the user assumes all risk associated with its installation and use. SEAT6 is not liable for loss of or damage to any property, equipment, or persons resulting from improper installation, overloading, misuse, or use outside these instructions.

Questions? hello@seat6.shop

