

OC1/OC2 Iako Clamp Mount

IM-150-C

Quick-release clamp mount for OC1 and OC2 iakos

WHAT'S INCLUDED

- 1x IM-150-C Clamp Mount
- 1x Knob & Nut for camera mount
- Neoprene padding (pre-installed)

WHAT YOU'LL NEED

- Your OC1/OC2 iako (~1.25" / ~32mm diameter)
- Your GoPro or compatible camera

INSTALLATION

Inspect neoprene pad before each use.

1. Open the cam lever and place the mount over your iako at your desired position, with the knob and lever pointing towards the rear (stern) of the boat.
2. Adjust the hook in or out to fit your iako diameter, then close the cam lever. The mount should sit snug enough that it won't easily twist around the iako — hand-tighten the hook, do not overtighten.
3. Attach your camera to the GoPro-compatible mount interface
4. Give the camera a firm shake to confirm it is seated securely before paddling.
5. When finished, rinse the entire mount with fresh water.

⚠ IMPORTANT

1. Designed for OC1/OC2 iakos ~1.25" in diameter. Use on undersized or oversized iakos may result in inadequate grip or damage to the mount.
2. Adjust the hook by hand only. Overtightening can strip the threads — once stripped, the hook will no longer hold adjustment and could fail during use.
3. Don't over-adjust the clamp tight against the iako. It should sit snug — enough that it won't easily twist — without excessive force on the cam lever or hook.
4. Inspect the cam lever and neoprene padding before every paddle. Do not use if either shows wear or damage.
5. We strongly recommend using the CLK Camera Leash Kit (sold separately) as a secondary retention system.

CARE

Rinse with fresh water after use. Do not use solvents or abrasive cleaners on the mount or neoprene padding.

DISCLAIMER

By purchasing and using this product, the user assumes all risk associated with its installation and use. SEAT6 is not liable for loss of or damage to any property, equipment, or persons resulting from improper installation, overloading, misuse, or use outside these instructions.

Questions? hello@seat6.shop

