

WEED DEFLECTOR

For OC-1 hulls

OC1-PR-1

WHAT'S INCLUDED

- 1x Weed Deflector
- 3M VHB tape pre-applied (red liner)
- alcohol pad

WHAT YOU'LL NEED

- Clean, dry hull surface
- Isopropyl alcohol (recommended)

INSTALLATION

This installation permanently bonds the deflector to your hull. Choose your location carefully before removing the tape liner.

1. Clean the mounting area with the provided alcohol pad and allow to dry completely.
2. Position the deflector on the hull just forward of the rudder. Pivot the rudder through its full range of motion to confirm it clears the deflector without contact.
3. When satisfied with placement, peel the red liner from the tape and press the deflector firmly onto the hull for 30 seconds.

⚠ IMPORTANT

1. Confirm rudder clearance before bonding — once the VHB liner is removed, placement is permanent.
2. Do not install on a wet or dirty hull — bond strength depends on a clean surface.
3. Do not paddle within 2-3 hours of installation. Bond continues to strengthen over 24 hours.

CARE

Rinse with fresh water after saltwater use. VHB bond is permanent — do not attempt to remove.

DISCLAIMER

By purchasing and using this product, the user assumes all risk associated with its installation and use. SEAT6 is not liable for loss of or damage to any property, equipment, or persons resulting from improper installation, overloading, misuse, or use outside these instructions.

Questions? hello@seat6.shop

