

Paddle Edge Guard

PEG

Clear protective film for paddle blade edges

WHAT'S INCLUDED

- 1x continuous strip, 60" long, 1/2" wide clear protective film
- 1x alcohol prep pad

WHAT YOU'LL NEED

- Scissors
- Your Paddle

INSTALLATION

Blade surface must be clean and dry before applying.

1. Clean the entire edge of the blade with the included alcohol prep pad and let it dry fully. Any dirt, wax, or residue will keep the film from bonding.
2. Starting at one end of the blade edge, peel back a few inches of the backing and press the film onto the edge with your thumb, centering it so it wraps evenly onto both faces.
3. Work slowly down the edge, peeling the backing a little at a time and pressing the film into place. Keep it centered and pull snug — no slack, no bubbles.
4. Follow the curve of the blade tip carefully; slow down and use small overlapping presses to keep the film smooth through the curve.
5. Once you reach the end, trim any excess with scissors and press the cut end down firmly.
6. Run your thumb along the entire length one more time to make sure it's fully adhered, especially at the tip and both ends.

⚠ IMPORTANT

1. Apply to a clean, dry blade only. Film applied over dirt or moisture will not bond properly and may peel prematurely.
2. Minor scratches on the film can often be smoothed out with light heat (direct sun or a hairdryer on low). Deep cuts or lifted edges mean it's time to replace the strip.
3. Not a substitute for proper paddle care — this reduces everyday wear from knocks and handling, it won't prevent damage from serious impacts.

CARE

Wipe clean with a damp cloth. Avoid solvents or abrasive cleaners on the film.

DISCLAIMER

By purchasing and using this product, the user assumes all risk associated with its installation and use. SEAT6 is not liable for loss of or damage to any property, equipment, or persons resulting from improper installation, overloading, misuse, or use outside these instructions.

Questions? hello@seat6.shop

