

PADDLE WALL HOOK

PWH-[1/2/3]

Holds 1/2/3 paddles
(dependent on model)

WHAT'S INCLUDED

- 1x Paddle Wall Hook
- 2x #8 self-drilling drywall anchors
- 2x #8 flat head screws

WHAT YOU'LL NEED

- A Phillips screwdriver.

INSTALLATION

This installation requires two holes in your wall. Choose your mounting location carefully.

1. Hold the hook against the wall at your desired height and mark both hole locations with a pencil.
2. If hitting a stud — drive screws directly. If drywall only — install anchors at your marks first.
3. *Hand-tighten only.* Stop when the back plate sits flush and firm against the wall.

⚠ IMPORTANT

1. No power tools. The print will crush before the hardware gives.
2. Do not exceed 6 lbs per mount.

CARE

Wipe clean with a damp cloth. Do not use solvents or abrasive cleaners.

DISCLAIMER

By purchasing and using this product, the user assumes all risk associated with its installation and use. SEAT6 is not liable for loss of or damage to any property, equipment, or persons resulting from improper installation, overloading, misuse, or use outside these instructions.

Questions? hello@seat6.shop

